

Displaying Cosmetic Threads in Assemblies

TITLE:	How to get your cosmetic threads to display in an assembly.
DATE:	March 2015
SUBJECT:	Showing Cosmetic Threads within Assemblies
ABSTRACT:	This article will go over the four options that can prevent cosmetic threads from displaying within assemblies.

View All Annotations

It is possible that cosmetic threads are hidden because they are filtered out under the "view" tab. To display cosmetic threads here, click View > All Annotations, as seen in the screenshot below.



Cosmetic Display Filter

This is another filter, in the annotation properties, that can cause cosmetic threads to not display. To enable cosmetic threads here: Right click on the Annotations folder > Details > Cosmetic threads checkbox. Please see the screenshots below for reference.



Ś solidw	ORKS File E	dit View	Insert Tool	s Toolbo	x Enterp	orise PDN	Window	Help 🖉 📄	• 🔌 • 🔓	- 🇞 -	1 - <table-cell></table-cell>
Bar esign tudy Dete	erence Clearance ction Verification	Hole Alignment	@ Measure Pr	Mass operties P	Section roperties	- 🚱 Sensor	Assembly Visualization	Assem <u>b</u> lyXpert	Curvature	Symmetry Check	Compare Documen
ssembly La	evaluate	Office Produ	ucts								
Assemil (Dr. Mistory Sensors Fro Top Top (n) (n) (n) (n) (n) (n) (n) (n)	Details Display Annotatis Show Feature Disolay Annotatis Show Feature Disolay Annotatis Show Reference (Show DimXyert A Josef Annotation Automatically Pit Enable Annotatio Go To Hide/Show Tree L Collapse Bems Customize Menu	ons nensions Dimensions Jimensions View View cce into Anno n View Visibil tems	tation Views			;	-				
	Annotati Displ C D D D F R D D Text scc Alw Disp in v D S C C D D D D D D D D D D D D D	on Pro ay filter osmetic atums atum ta eature o eference imXper ale: 1:: ays disp olay iter which ti olay ass assemi	perties t thread argets dimens t dimens t dimens 1 Jalay tex ms only argets argets play text t dimens t di t dimens t di t dimens t dimens t dimens t dimens t di	ions nsions isions t at th in the create nnnota	e view ed ations	Shi Ge No Sur Dis ne siz r orie s ompo	aded co ometric tes iface fir elds iplay all e intation	ismetic th toleranc nish types Car Car Ap	rreads es OK ncel elp ply		

Display Annotations

As a group, Annotations can be toggled on and off which can result in cosmetic threads not displaying. To turn on Annotations, Right Click the Annotations folder and select "Display Annotations". Below is a screenshot showing where the setting is located.



S SOLIDWORK	S File E	dit View	Insert 1	Tools Tool	box Enter	prise PDN	Window	Help 🧟 [) • 🔌 • [- 🎝 - 🖥	· •9 · [
Design Study *	Clearance Verification	Hole Alignment	<u> </u> Measure	Mass Properties	Section Properties	() Sensor	Assembly Visualization	Assem <u>b</u> lyXpert	Curvature	Symmetry Check	Comp. Docum
Assembly Layout	Evaluate	Office Prod	ucts							Ø	Q V
Image: Second	» Display State										
Annotations											
- Front Pla	Details					1					
Right Pla	Display Anno	otations				•					
	Show Feature Show Reference	e Dimensior nce Dimensi	ons			-					
	Show DimXp	ert Annotat	ions								
~	Insert Annot Automatical	ation View ly Place into	Annotatio	in Views							
	Enable Anno	tation View	Visibility								
	Go To										
	Hide/Show T	ree Items									
	Collapse iten	ns									
	Customize N	lenu									

Assembly Settings for All Components

This is to ensure that your annotation settings are applied to all components. Again, right click the Annotations folder > details > Use assembly settings for all components checkbox. Please see the screenshots below for reference.





Annotation Properties	X					
Display filter Cosmetic threads Datums Datums Datum targets Feature dimensions Reference dimensions DimYnett dimensions	 Shaded cosmetic threads Geometric tolerances Notes Surface finish Welds Display all times 					
Text scale: 1:1 Image: Instruction of the state state state state state of the state state state of the state state of the state state of the state state of the state						
Use assembly setting for al	Cancel Cancel Apply					

Combinations that Display

The table below shows which combinations of settings will allow cosmetic threads to display.

View All Annotations	Cosmetic Threads	Display Annotations	Use Assembly Settings for all components	Display of Cosmetic Threads
OFF	OFF	OFF	OFF	Hidden
OFF	ON	OFF	OFF	Hidden
ON	OFF	OFF	OFF	Shown
ON	ON	OFF	OFF	Shown
OFF	OFF	ON	OFF	Hidden
OFF	ON	ON	OFF	Hidden
ON	OFF	ON	OFF	Shown
ON	ON	ON	OFF	Shown
OFF	OFF	OFF	ON	Hidden
OFF	ON	OFF	ON	Hidden
ON	OFF	OFF	ON	Hidden
ON	ON	OFF	ON	Hidden
OFF	OFF	ON	ON	Hidden
OFF	ON	ON	ON	Hidden
ON	OFF	ON	ON	Hidden
ON	ON	ON	ON	Shown