

Eureka Install for a Sentinel Dongle

Setting up the Eureka License Folder

1. Go to your local disk (C:) and create a folder "Eureka License". This is the recommended folder name and location; however, you can choose to put the license file in a different location if you prefer.



Placing the License File in Eureka License Folder

1. Open the email you received with the License File attached, click on the drop-down arrow, and select save as.



2. Go to the Eureka License folder you created and click "Save".

≥ Save Attachment				\times
\leftarrow \rightarrow \checkmark \uparrow \frown « Local Disk (C:) \rightarrow Eureka Li	cense v	C Search Eu	ureka License	Q
Organize 🔻 New folder			≣ ▪	?
> Name	Date modified	Туре	Size	
> Croborisusa_valkyrieprecision_4E9B9D1C.lic	12/21/2022 9:02 AM	LIC File	7 KB	
File name: roborisusa_johncook_789230237.lic				~
Save as type: LIC File (*.lic)				~
∧ Hide Folders		Tools 👻 Sav	/e Cance	<u>ا</u>

Installing Eureka for a Sentinel Dongle

1. Open the eureka setup .exe file

影 setup_eureka_x64_10.3.12942.0.exe

2. Allow app to make changes to your device, click the "Yes" button.



3. To select language, click the drop-down arrow and select a language. In my case, I want English so I will select that option.

Select	Setup Language	×
Ø	Select the language to use during the installation.	
	English	\odot
	Čeština — Deutsch	L
C	English	
4. Clic	Français Italiano Korean Magyar Polski Português (Portugal) Türkçe български Русский 日本語 简体中文 k "OK".	
Sel	ect Setup Language	\times
Ī	Select the language to use during the installation.	!
	English	\sim
	ОК	Cancel
	براجعا بالمتابع بملجم مسم مسم ملاسم	المحسم مالا

5. Accept agreement by clicking in the radial button, then clicking next.



6. Select destination location and click "Next".

📸 Setup - Eureka10 10.3.12942.0	_		×
Select Destination Location Where should Eureka 10 be installed?		(E
Setup will install Eureka 10 into the following folder.			
To continue, click Next. If you would like to select a different folder, clic	ck Brow	ise.	
C:\Program Files\Roboris\EUREKA10.X	Bro	wse	ノ
At least 281.1 MB of free disk space is required.			
< Back Next >		Can	cel

7. Select "License File + Sentinel Dongle".

📸 Setup - Eureka10 10.3.12942.0	_		×
Select Additional Tasks Which additional tasks should be performed?		(E
Select the additional tasks you would like Setup to perform while in then click Next.	nstalling Eu	reka 10,	
License Type			
O Hard Disk Code or Deskey (Stand-alone)			
License File + Sentinel Dongle			
License File + Hard Disk Code			
C License file + Authentication code			
 Network License (Deskey) 			
 Network License (Sentinel or Roboris Server) 			
DK2 Drivers			
○ Client version			
< Back N	ext >	Can	cel

8. Scroll down, and in the DK2 Driver section, select "Skip driver installation", then click "Next".

📸 Setup - Eureka10 10.3.12942.0	_		×
Select Additional Tasks Which additional tasks should be performed?		(E
Select the additional tasks you would like Setup to perform while inst then click Next.	alling Eu	reka 10,	
License File + Hard Disk Code			
 License file + Authentication code 			
 Network License (Deskey) 			
 Network License (Sentinel or Roboris Server) 			
DK2 Drivers			
Client version			
Server version			
• Skip driver installation			
< Back Nex	t>	Car	ncel

9. In the Ready to Install window, click "Install".

🐞 Setup - Eureka10 10.3.12942.0 —		\times
Ready to Install Setup is now ready to begin installing Eureka 10 on your computer.	(E
Click Install to continue with the installation, or click Back if you want to review or change any settings.	or	
Dependencies to install:		
Destination location: C:\Program Files\Roboris\EUREKA10.X		
4	•	
< Back Install	Cano	el

10. In the completing the Eureka10 Setup Wizard window that pops up, click "Finish".



- 11. Plug the Sentinel Dongle into a USB port on your computer.
- 12. Open Eureka, when the bellow dialog box opens, click the button with the three dots.

Select the license file	X
789230237	
OK Cancel	

13. Navigate to your license file, select it, and click "Open".

Open					×
$\leftarrow \ \ \rightarrow \ \ \lor$	\uparrow	📒 « Local Disk (C:) > Eureka Li	cense v C	Search Eureka License	Q
Organize 🔻	New f	older		≣ ▼ [
e N	lame	^	Date modified	lype Size	
	roborisu	isa_valkyrieprecision_4E9B9D1C.lic	12/21/2022 9:02 AM	LIC File	7 KB
~ 1					
	Fil	le name: roborisusa_valkyrieprecisi	on_4E9B9D1C.lic	 License file(*.lic) 	~
				Open Car	icel

14. Click "OK" and Eureka will open.

Select the license file	×
789230237	
C:\Eureka License\roborisusa_valkyrieprecision_4E9B9D 1C.lic	
OK Cancel	

Additional Comments

- 1. You will need to create a Eureka License folder on the C drive of any other computers you will be using Eureka on and past a copy of the license file in the folder.
- 2. Only the computer with the Sentinel Dongle will be able to open Eureka.